

## **Cary#26WRPP - MR50-5 Pump Spout Attachment Instructions**

**Step 1: Remove the pump from the box and take out the spout adapter and the main pump assembly.**



**Step 2: Screw the spout adaptor onto the main pump assembly.**



**Step 3: Attach dip tube and position over spout. You may need to cut dip tube to achieve desired length.**



**Step 4: Screw pump onto spout. Pump handle a few times to prime pump, then utilize as needed. Reverse instructions to disassemble.**

