

Part#: 68W49L



Part#	Size	Description	Material	#/Case
68W49L	48mm	Pressure Sensitive Liner Insert	FS22	10000/Case



Supplied By: **The Cary Company**
Ph: 630-629-6600
www.thecarycompany.com



Pressure Sensitive Liner Application

Pressure sensitive liners have adhesive on one side and are designed to stick on the rim of a container. When the container is closed and pressure is applied to the cap, the adhesive becomes activated, which creates a seal.



Before applying the cap with liner, wipe the mouth of the opening thoroughly to clear of liquid and/or solids.



Make sure the liner and cap are tightly secured on the container and wait at least 24 hours before removing cap.

Product Disclaimer

Due to product integrity and increased regulation, The Cary Company does not allow returns of Pressure Sensitive liners. All Pressure Sensitive liners are made to order and it is the customer's responsibility to request samples for testing purposes before purchasing. Pressure Sensitive liners are not recognized by the FDA as tamper evident and are not recommended for use with liquid products. See heat induction liners for tamper evidence.

Recommendations

The following recommendations will help to promote the best possible adhesion performance and seal from pressure sensitive liners to containers:

- Keep pressure sensitive liners away from direct heat and sunlight.
- Store Pressure Sensitive liners and caps in temperatures between 60 and 80 degrees and allow materials to adjust to the conditions of the processing room for at least 48 hours before capping.
- PS liners should be used 30 days after being received.
- All bottles should have an uncontaminated and dry opening surface for a solid seal.
- All Caps should be sealed for at least 24 hours after applying the Pressure Sensitive liner.

If there are any questions please call 630-376-2400 or e-mail sales@thecarycompany.com and talk to one of our friendly Solution Providers.